

PHOTO	PRODUCT NUMBER	PRODUCT NAME	PRODUCT DESCRIPTION	PRODUCT DESCRIPTION
	1386	7.5FT BOSTON TRE	Christmas Tree- comes in 3 parts	Follow assembly instructions
	1387	8FT SPRUCE	Christmas Tree- comes in 3 parts	Follow assembly instructions
	1388	MIXED 50PK BAUBL	Pack of 50 shatterproof baubles.	<ul style="list-style-type: none"> •This is a decoration not a toy •Indoor use only
	1389	MIXED 50PK BAUBL	Pack of 50 shatterproof baubles.	<ul style="list-style-type: none"> •This is a decoration not a toy •Indoor use only
	1390	MIXED 50PK BAUBL	Pack of 50 shatterproof baubles.	<ul style="list-style-type: none"> •This is a decoration not a toy •Indoor use only
	1391	9PK BAUBLE	pack of 9 shatterproof baubles	<ul style="list-style-type: none"> •This is a decoration not a toy •Indoor use only
	1392	9PK BAUBLE	pack of 9 shatterproof baubles	<ul style="list-style-type: none"> •This is a decoration not a toy •Indoor use only
	1393	9PK BAUBLE	pack of 9 shatterproof baubles	<ul style="list-style-type: none"> •This is a decoration not a toy •Indoor use only
	1394	9PK BAUBLE	pack of 9 shatterproof baubles	<ul style="list-style-type: none"> •This is a decoration not a toy •Indoor use only
	1395	FROSTED BALL	100 led frosted ball lights - multi coloured light Distance from plug to first bulb: 5M approx. Overall length: 15M approx. Bulb spacing: 10cm	<ul style="list-style-type: none"> •This light set is suitable for indoor and outdoor use but the transformer must always be located indoors •This lighting chain is a decoration, not a toy - not suitable for children under 14 years of age due to small parts that may constitute a choking hazard •Please keep it unplugged while still in the packaging •The bulbs are not replaceable •The cable must be fully extended prior to use •Only use the included IP20 adaptor •Caution: when connecting the lighting to the adaptor, the screw cap must be firmly tightened •If the adaptor and/or the article are damaged or do not work properly, the whole article should be disposed of
	1396	FROSTED BALL	100 led frosted ball lights - white light Distance from plug to first bulb: 5M approx. Overall length: 15M approx. Bulb spacing: 10cm	<ul style="list-style-type: none"> •This light set is suitable for indoor and outdoor use but the transformer must always be located indoors •This lighting chain is a decoration, not a toy - not suitable for children under 14 years of age due to small parts that may constitute a choking hazard •Please keep it unplugged while still in the packaging •The bulbs are not replaceable •The cable must be fully extended prior to use •Only use the included IP20 adaptor •Caution: when connecting the lighting to the adaptor, the screw cap must be firmly tightened •If the adaptor and/or the article are damaged or do not work properly, the whole article should be disposed of

	1397	FROSTED BALL	100 led frosted ball lights- red light Distance from plug to first bulb: 5M approx. Overall length: 15M approx. Bulb spacing: 10cm	<ul style="list-style-type: none"> •This light set is suitable for indoor and outdoor use but the transformer must always be located indoors •This lighting chain is a decoration, not a toy - not suitable for children under 14 years of age due to small parts that may constitute a choking hazard •Please keep it unplugged while still in the packaging •The bulbs are not replaceable •The cable must be fully extended prior to use •Only use the included IP20 adaptor •Caution: when connecting the lighting to the adaptor, the screw cap must be firmly tightened •If the adaptor and/or the article are damaged or do not work properly, the whole article should be disposed of
	1398	500 LED LIGHTS	500 led string light- suitable for both indoor and outdoor use Distance from plug to first bulb: 5M approx. Overall length: 17.5M approx. Bulb spacing: 2.5cm	<ul style="list-style-type: none"> •This light set is suitable for indoor and outdoor use but the transformer must always be located indoors •This lighting chain is a decoration, not a toy - not suitable for children under 14 years of age due to small parts that may constitute a choking hazard •Please keep it unplugged while still in the packaging •The bulbs are not replaceable •The cable must be fully extended prior to use •Only use the included IP20 adaptor •Caution: when connecting the lighting to the adaptor, the screw cap must be firmly tightened •If the adaptor and/or the article are damaged or do not work properly, the whole article should be disposed of
	1399	500 LED LIGHTS	500 led string light- suitable for both indoor and outdoor use Distance from plug to first bulb: 5M approx. Overall length: 17.5M approx. Bulb spacing: 2.5cm	<ul style="list-style-type: none"> •This light set is suitable for indoor and outdoor use but the transformer must always be located indoors •This lighting chain is a decoration, not a toy - not suitable for children under 14 years of age due to small parts that may constitute a choking hazard •Please keep it unplugged while still in the packaging •The bulbs are not replaceable •The cable must be fully extended prior to use •Only use the included IP20 adaptor •Caution: when connecting the lighting to the adaptor, the screw cap must be firmly tightened •If the adaptor and/or the article are damaged or do not work properly, the whole article should be disposed of
	1400	500 LED LIGHTS	both indoor and outdoor use Distance from plug to first bulb: 5M approx. Overall length: 17.5M approx. Bulb spacing: 2.5cm	<ul style="list-style-type: none"> •This lighting chain is a decoration, not a toy - not suitable for children under 14 years of age due to small parts that may constitute a choking hazard •Please keep it unplugged while still in the packaging •The bulbs are not replaceable •The cable must be fully extended prior to use •Only use the included IP20 adaptor •Caution: when connecting the lighting to the adaptor, the screw cap must be firmly tightened
	1401	200 DIAMOND LIGH	200 led string lights with diamond shape bulb. Coming in a set of 200 LED bulbs, they're suitable for both indoor and outdoor use. Timer and dimmer switch included. Distance from plug to first bulb: 5M approx. Overall length: 12.5M approx.	<ul style="list-style-type: none"> •This lighting chain is a decoration, not a toy - not suitable for children under 14 years of age due to small parts that may constitute a choking hazard •Please keep it unplugged while still in the packaging •The bulbs are not replaceable •The cable must be fully extended prior to use •Only use the included IP20 adaptor •Caution: when connecting the lighting to the adaptor, the screw cap must be firmly tightened •If the adaptor and/or the article are damaged or do not work properly, the whole article should be disposed of
	1402	20PK BATTERY LED	battery pack light with 20 LED Bulbs. (3 AA batteries required-not included) Suitable for indoor use only.	indoor use only
	1403	20PK BATTERY LED	battery pack light with 20 LED Bulbs. (3 AA batteries required-not included) Suitable for indoor use only.	indoor use only

	1404	20PK BATTERY LED	battery pack light with 20 LED Bulbs. (3 AA batteries required-not included) Suitable for indoor use only.	indoor use only
	1405	192PK BATTERY LE	battery pack light with 192 LED bulbs, suitable for both indoor and outdoor use. Includes 8 plus memory functions and timer feature. 3x AA batteries required-not includes	suitable for indoor and outdoor use
	1406	192PK BATTERY LE	battery pack light with 192 LED bulbs, suitable for both indoor and outdoor use. Includes 8 plus memory functions and timer feature. 3x AA batteries required-not includes	suitable for indoor and outdoor use
	1407	100PK FILAMENT	battery operated 100 microfilament lights on wire.Requires 3 x AA batteries (not included) Suitable for indoor use only	suitable for indoor use only
	1408	500 CLUSTER LIGH	500 cluster led bulb string light-suitable for both indoor and outdoor use Distance from plug to first bulb: 3M approx. Overall length:10M approx. Bulb spacing: 1.5cm	<ul style="list-style-type: none"> •The bulbs are permanently wired and are not replaceable •Do not illuminate the set whilst in the packaging •The cable must be fully extended prior to use •Do not electrically connect this set to any other set by cutting or joining sets together •Do not use if the insulation of the light set or cable is damaged •The external flexible cord of this light set cannot be replaced: if the cord is damaged the light set must be destroyed •Thoroughly inspect light set before use •Please ensure lights are disconnected from the mains supply when there are no adults present or when light set is not in use •The set is suitable for indoor or temporary outdoor use only •Set must be plugged into an indoor socket only •Unplug when not in use or when carrying out maintenance or adjustment •Transformer will become quite warm in use, so do not place on or near surfaces which could be affected by heat such as table tops or carpets •Keep out of reach of young children
	1409	500 CLUSTER LIGH	500 cluster led bulb string light-suitable for both indoor and outdoor use Distance from plug to first bulb: 3M approx. Overall length: 10M approx. Bulb spacing: 1.5cm	<ul style="list-style-type: none"> •The bulbs are permanently wired and are not replaceable •Do not illuminate the set whilst in the packaging •The cable must be fully extended prior to use •Do not electrically connect this set to any other set by cutting or joining sets together •Do not use if the insulation of the light set or cable is damaged •The external flexible cord of this light set cannot be replaced: if the cord is damaged the light set must be destroyed •Thoroughly inspect light set before use •Please ensure lights are disconnected from the mains supply when there are no adults present or when light set is not in use •The set is suitable for indoor or temporary outdoor use only •Set must be plugged into an indoor socket only •Unplug when not in use or when carrying out maintenance or adjustment •Transformer will become quite warm in use, so do not place on or near surfaces which could be affected by heat such as table tops or carpets •Keep out of reach of young children

	1410	1000 CLUSTER	1000 cluster led bulb string light-suitable for both indoor and outdoor use Distance from plug to first bulb: 3M approx. Overall length: 17M approx. Bulb spacing: 1.5cm	<ul style="list-style-type: none"> •The bulbs are permanently wired and are not replaceable •Do not illuminate the set whilst in the packaging •The cable must be fully extended prior to use •Do not electrically connect this set to any other set by cutting or joining sets together •Do not use if the insulation of the light set or cable is damaged •The external flexible cord of this light set cannot be replaced: if the cord is damaged the light set must be destroyed •Thoroughly inspect light set before use •Please ensure lights are disconnected from the mains supply when there are no adults present or when light set is not in use •The set is suitable for indoor or temporary outdoor use only •Set must be plugged into an indoor socket only •Unplug when not in use or when carrying out maintenance or adjustment •Transformer will become quite warm in use, so do not place on or near surfaces which could be affected by heat such as table tops or carpets •Keep out of reach of young children
	1411	1000 CLUSTER	1000 cluster led bulb string light-suitable for both indoor and outdoor use Distance from plug to first bulb: 3M approx. Overall length: 17M approx. Bulb spacing: 1.5cm	<ul style="list-style-type: none"> •The bulbs are permanently wired and are not replaceable •Do not illuminate the set whilst in the packaging •The cable must be fully extended prior to use •Do not electrically connect this set to any other set by cutting or joining sets together •Do not use if the insulation of the light set or cable is damaged •The external flexible cord of this light set cannot be replaced: if the cord is damaged the light set must be destroyed •Thoroughly inspect light set before use •Please ensure lights are disconnected from the mains supply when there are no adults present or when light set is not in use •The set is suitable for indoor or temporary outdoor use only •Set must be plugged into an indoor socket only •Unplug when not in use or when carrying out maintenance or adjustment •Transformer will become quite warm in use, so do not place on or near surfaces which could be affected by heat such as table tops or carpets •Keep out of reach of young children
	1412	STAR FILAMENTS	battery pack star light with 40 bulbs. Requires 3 x AA batteries (not included). Suitable for indoor use only	<ul style="list-style-type: none"> •Read instructions carefully before use •Indoor use only •Keep out of reach of children
	1413	BEADED TWIGS	90cm beaded twig with led bulbs. Requires 3 x AA batteries (not included). Suitable for indoor use only.	<ul style="list-style-type: none"> •Read instructions carefully before use •Indoor use only •Keep out of reach of children
	1414	BEADED TWIGS	90cm beaded twig with led bulbs. Requires 3 x AA batteries (not included). Suitable for indoor use only.	<ul style="list-style-type: none"> •Read instructions carefully before use •Indoor use only •Keep out of reach of children
	1415	BEADED20PKLIGHTS	Jewel battery pack light, with 20 LED bulbs. •Requires 2 x AA batteries (not included) Indoor use only	<ul style="list-style-type: none"> •Read instructions carefully before use •Indoor use only •Keep out of reach of children
	1416	BEADED20PKLIGHTS	Pearl battery pack light with 20 led bulbs, required 2 x AA batteries (not included) for indoor use only.	<ul style="list-style-type: none"> •Read instructions carefully before use •Indoor use only •Keep out of reach of children
	1417	100 MINI LIGHTS	LED lights	<ul style="list-style-type: none"> •Read instructions carefully before use •Indoor use only •Keep out of reach of children

	1418	LEAF LED LIGHTS	LED lights	<ul style="list-style-type: none"> •Read instructions carefully before use •Indoor use only •Keep out of reach of children
	1419	PEARL LED LIGHTS	LED lights	<ul style="list-style-type: none"> •Read instructions carefully before use •Indoor use only •Keep out of reach of children
	1420	WHITE WREATH	wreath with frosted tips, acorn and white berry detail	<ul style="list-style-type: none"> •This is a decoration not a toy •Indoor use only •Warning: Choking hazard - small parts •Keep out of reach of young children •Keep away from all sources of ignition
	1421	GLITTER WREATH	gold glitter wreath	<ul style="list-style-type: none"> •This is a decoration not a toy •Indoor use only •Warning: Choking hazard - small parts •Keep out of reach of young children •Keep away from all sources of ignition
	1422	RED WREATH	green foliage wreath with red velvet poinsettia, berry and acorn detail	<ul style="list-style-type: none"> •This is a decoration not a toy •Indoor use only •Warning: Choking hazard - small parts •Keep out of reach of young children •Keep away from all sources of ignition
	1423	FROSTED WREATH	full white frosted wreath with silver and white baubles	<ul style="list-style-type: none"> •This is a decoration not a toy •Indoor use only •Warning: Choking hazard - small parts •Keep out of reach of young children •Keep away from all sources of ignition
	1428	LED TREE	6ft tree with led, pearl and diamante droplet detail on each branch	suitable for indoor and outdoor use, mains cable must be indoor only.
	1429	LED TREE	6ft Tree with LED, branch and berry detail on each tree	suitable for indoor use only
	1430	PRE LIT TREE	1.8m tree with 426 lights	suitable for indoor use only
	1433	WHITE 6FTGARLAND	6ft garland with frosted tips, acorns and white berry detail	<ul style="list-style-type: none"> •This is a decoration not a toy •Indoor use only •Warning: Choking hazard - small parts •Keep out of reach of young children •Keep away from all sources of ignition
	1434	FROSTED GARLAND	6ft full snowy garland with pink bauble detail	<ul style="list-style-type: none"> •This is a decoration not a toy •Indoor use only •Warning: Choking hazard - small parts •Keep out of reach of young children •Keep away from all sources of ignition









	1435	FROSTED GARLAND	6ft full snowy garland with white and silver bauble detail	<ul style="list-style-type: none"> •This is a decoration not a toy •Indoor use only •Warning: Choking hazard - small parts •Keep out of reach of young children •Keep away from all sources of ignition
	1436	RED GARLAND	6ft green garland with red ponsettia, red berries and acorns	<ul style="list-style-type: none"> •This is a decoration not a toy •Indoor use only •Warning: Choking hazard - small parts •Keep out of reach of young children •Keep away from all sources of ignition
	1437	GLITTER GARLAND	gold glitter leaf garland	<ul style="list-style-type: none"> •This is a decoration not a toy •Indoor use only •Warning: Choking hazard - small parts •Keep out of reach of young children •Keep away from all sources of ignition
	1438	GLITTER GARLAND	silver glitter leaf garland	<ul style="list-style-type: none"> •This is a decoration not a toy •Indoor use only •Warning: Choking hazard - small parts •Keep out of reach of young children •Keep away from all sources of ignition
	1439	OUTDOOR LAMPOST	Bright white acrylic outdoor LED lamppost.	<ul style="list-style-type: none"> •Read instructions carefully before use •Lamps are not replaceable •Keep away from fire and sources of heat •Use only with supplied transformer •If the cable of the light set is damaged, it cannot be repaired and the light set must be destroyed •For indoor and outdoor use •Always connect the mains plug to an indoor socks or an approved outdoor socket •This product is intended for use as a Christmas decoration only, it is not intended for household room illumination
	1440	OUTDOOR LED TREE	Bright white LED outdoor cone Tree. Mutli function LED	<ul style="list-style-type: none"> •Lamps are not replaceable •Keep away from fire and sources of heat •Use only with supplied transformer •If the cable of the light set is damaged, it cannot be repaired and the light set must be destroyed •For indoor and outdoor use •Always connect the mains plug to an indoor socks or an approved outdoor socket •This product is intended for use as a Christmas decoration only, it is not intended for household room illumination
	1441	OUTDOOR REINDEER	warm white LED acrylic outdoor reindeer.	<ul style="list-style-type: none"> •Lamps are not replaceable •Keep away from fire and sources of heat •Use only with supplied transformer •If the cable of the light set is damaged, it cannot be repaired and the light set must be destroyed •For indoor and outdoor use •Always connect the mains plug to an indoor socks or an approved outdoor socket •This product is intended for use as a Christmas decoration only, it is not intended for household room illumination

	1442	OUTDOOR PENGUIN	bright white outdoor penguin decoration.	<ul style="list-style-type: none"> •Lamps are not replaceable •Keep away from fire and sources of heat •Use only with supplied transformer •If the cable of the light set is damaged, it cannot be repaired and the light set must be destroyed •For indoor and outdoor use •Always connect the mains plug to an indoor socks or an approved outdoor socket •This product is intended for use as a Christmas decoration only, it is not intended for household room illumination
	1443	LAMPOST LARGE	LED LAMPOST WITH WREATH DETAIL. Requires3x AA batteries (not included)	<ul style="list-style-type: none"> •This is a decoration not a toy •Indoor use only •Read instructions carefully before use •Keep out of reach of children
	1444	LAMPOST SMALL	LED LAMPOST WITH WREATH DETAIL. Batteries included	<ul style="list-style-type: none"> •This is a decoration not a toy •Indoor use only •Read instructions carefully before use •Keep out of reach of children
	1445	LAMPOST LARGE	LED LAMPOST WITH WREATH DETAIL. Requires 3x AA batteries (not included)	<ul style="list-style-type: none"> •This is a decoration not a toy •Indoor use only •Read instructions carefully before use •Keep out of reach of children
	1446	LAMPOST SMALL	LED LAMPOST WITH WREATH DETAIL	<ul style="list-style-type: none"> •This is a decoration not a toy •Indoor use only •Read instructions carefully before use •Keep out of reach of children
	1447	LAMPOST LARGE	LED LAMPOST WITH FOLIAGE DETAIL. Requires 3 x AA batteries, not included	<ul style="list-style-type: none"> •This is a decoration not a toy •Indoor use only •Read instructions carefully before use •Keep out of reach of children
	1448	LAMPOST SMALL	LED LAMPOST WITH FOLIAGE DETAIL. Batteries included.	<ul style="list-style-type: none"> •This is a decoration not a toy •Indoor use only •Read instructions carefully before use •Keep out of reach of children
	1449	STAR TREE TOPPER	gold glitter star tree topper	<ul style="list-style-type: none"> •Indoor use only •Read instructions carefully before use •Keep out of reach of children
	1450	STAR TREE TOPPER	silver glitter star tree toppers	<ul style="list-style-type: none"> •This is a decoration not a toy •Indoor use only •Read instructions carefully before use •Keep out of reach of children
	1451	ANGEL TREE TOPPER	angel tree topper	<ul style="list-style-type: none"> •This is a decoration not a toy •Indoor use only •Read instructions carefully before use •Keep out of reach of children

	1452	HANGING PINECONE	hanging pinecone decoration with velvet ribbon.	<ul style="list-style-type: none"> •This is a decoration not a toy •Indoor use only •Warning: Choking hazard - small parts •Keep out of reach of young children •Keep away from all sources of ignition •Delicate item - handle with care
	1453	HANGING PINECONE	hanging pinecone decoration with velvet ribbon.	<ul style="list-style-type: none"> •This is a decoration not a toy •Indoor use only •Warning: Choking hazard - small parts •Keep out of reach of young children •Keep away from all sources of ignition •Delicate item - handle with care
	1454	LONG TAIL BIRD	gold and pink bird with feather tail, clip on base of bird for easy decoration.	<ul style="list-style-type: none"> •This is a decoration not a toy •Indoor use only •Warning: Choking hazard - small parts •Keep out of reach of young children •Keep away from all sources of ignition •Delicate item - handle with care
	1455	LONG TAIL BIRD	gold and pink bird with feather tail, clip on base of bird for easy decoration.	<ul style="list-style-type: none"> •This is a decoration not a toy •Indoor use only •Warning: Choking hazard - small parts •Keep out of reach of young children •Keep away from all sources of ignition •Delicate item - handle with care
	1456	BEADED BIRD	beaded bird decoration with clip on base of bird for easy decoration.	<ul style="list-style-type: none"> •This is a decoration not a toy •Indoor use only •Warning: Choking hazard - small parts •Keep out of reach of young children •Keep away from all sources of ignition •Delicate item - handle with care
	1457	BEADED BIRD	beaded bird decoration with clip on base of bird for easy decoration	<ul style="list-style-type: none"> •This is a decoration not a toy •Indoor use only •Warning: Choking hazard - small parts •Keep out of reach of young children •Keep away from all sources of ignition •Delicate item - handle with care
	1458	BEADED BIRD	beaded bird decoration with clip on base of bird for easy decoration	<ul style="list-style-type: none"> •This is a decoration not a toy •Indoor use only •Warning: Choking hazard - small parts •Keep out of reach of young children •Keep away from all sources of ignition •Delicate item - handle with care
	1459	BEADED BIRD	beaded bird decoration with clip on base of bird for easy decoration	<ul style="list-style-type: none"> •This is a decoration not a toy •Indoor use only •Warning: Choking hazard - small parts •Keep out of reach of young children •Keep away from all sources of ignition •Delicate item - handle with care

	1460	FLOWER WITH CLIP	glitter flower with clip for easy decoration	<ul style="list-style-type: none"> •This is a decoration not a toy •Indoor use only •Warning: Choking hazard - small parts •Keep out of reach of young children •Keep away from all sources of ignition •Delicate item - handle with care
	1461	FLOWER WITH CLIP	glitter flower with clip for easy decoration	<ul style="list-style-type: none"> •This is a decoration not a toy •Indoor use only •Warning: Choking hazard - small parts •Keep out of reach of young children •Keep away from all sources of ignition •Delicate item - handle with care
	1462	FLOWER WITH CLIP	glitter flower with clip for easy decoration	<ul style="list-style-type: none"> •This is a decoration not a toy •Indoor use only •Warning: Choking hazard - small parts •Keep out of reach of young children •Keep away from all sources of ignition •Delicate item - handle with care
	1463	VELVET FLOWER WITH CLIP	velvet embellished flower with clip for easy decoration	<ul style="list-style-type: none"> •This is a decoration not a toy •Indoor use only •Warning: Choking hazard - small parts •Keep out of reach of young children •Keep away from all sources of ignition •Delicate item - handle with care
	1464	VELVET FLOWER WITH CLIP	velvet embellished flower with clip for easy decoration	<ul style="list-style-type: none"> •This is a decoration not a toy •Indoor use only •Warning: Choking hazard - small parts •Keep out of reach of young children •Keep away from all sources of ignition •Delicate item - handle with care
	1465	VELVET FLOWER WITH CLIP	velvet embellished flower with clip for easy decoration	<ul style="list-style-type: none"> •Warning: Choking hazard - small parts •Keep out of reach of young children •Keep away from all sources of ignition •Delicate item - handle with care
	1466	VELVET ROSE	velvet embellished rose with clip for easy decoration	<ul style="list-style-type: none"> •This is a decoration not a toy •Indoor use only •Warning: Choking hazard - small parts •Keep out of reach of young children •Keep away from all sources of ignition
	1467	VELVET ROSE	velvet embellished rose with clip for easy decoration	<ul style="list-style-type: none"> •This is a decoration not a toy •Indoor use only •Warning: Choking hazard - small parts •Keep out of reach of young children •Keep away from all sources of ignition •Delicate item - handle with care

	1468	VELVET ROSE	velvet embellished rose with clip for easy decoration	<ul style="list-style-type: none"> •This is a decoration not a toy •Indoor use only •Warning: Choking hazard - small parts •Keep out of reach of young children •Keep away from all sources of ignition •Delicate item - handle with care 		
	1469	VELVET ROSE	velvet embellished rose with clip for easy decoration	<ul style="list-style-type: none"> •This is a decoration not a toy •Indoor use only •Warning: Choking hazard - small parts •Keep out of reach of young children •Keep away from all sources of ignition •Delicate item - handle with care 		
	1470	PONSETTIA W CLIP	fabric poinsettia with clip for easy decoration	<ul style="list-style-type: none"> •This is a decoration not a toy •Indoor use only •Warning: Choking hazard - small parts •Keep out of reach of young children •Keep away from all sources of ignition •Delicate item - handle with care 		
	1471	PONSETTIA W CLIP	fabric poinsettia with clip for easy decoration	<ul style="list-style-type: none"> •This is a decoration not a toy •Indoor use only •Warning: Choking hazard - small parts •Keep out of reach of young children •Keep away from all sources of ignition •Delicate item - handle with care 		
	1472	Carolyn Donnelly 4pk Tree Decorations	Festive Star and Heart bell embellished decorations	<table border="1" data-bbox="922 798 1384 949"> <tr> <td style="text-align: center;"> <small>WARNING:</small> CHOKING HAZARD - Small parts This is a Christmas decoration, NOT A TOY Keep out of reach of young children For decorative purpose only Retain information for future reference </td> <td style="text-align: center;"> <small>ADVERTENCIA: PELIGRO DE ASFIXIA</small> -Contiene piezas pequeñas Esto es un artículo de decoración navideña, NO ES UN JUGUETE Mantener fuera del alcance de los niños pequeños Sólo con fines decorativos Guardar esta información para futuras referencias </td> </tr> </table>	<small>WARNING:</small> CHOKING HAZARD - Small parts This is a Christmas decoration, NOT A TOY Keep out of reach of young children For decorative purpose only Retain information for future reference	<small>ADVERTENCIA: PELIGRO DE ASFIXIA</small> -Contiene piezas pequeñas Esto es un artículo de decoración navideña, NO ES UN JUGUETE Mantener fuera del alcance de los niños pequeños Sólo con fines decorativos Guardar esta información para futuras referencias
<small>WARNING:</small> CHOKING HAZARD - Small parts This is a Christmas decoration, NOT A TOY Keep out of reach of young children For decorative purpose only Retain information for future reference	<small>ADVERTENCIA: PELIGRO DE ASFIXIA</small> -Contiene piezas pequeñas Esto es un artículo de decoración navideña, NO ES UN JUGUETE Mantener fuera del alcance de los niños pequeños Sólo con fines decorativos Guardar esta información para futuras referencias					
	1473	2PK BEADED ANIMAL	2PK BEADED ANIMAL HANGING DECORATION	<table border="1" data-bbox="922 981 1384 1125"> <tr> <td style="text-align: center;"> <small>WARNING:</small> CHOKING HAZARD - Small parts This is a Christmas decoration, NOT A TOY Keep out of reach of young children For decorative purpose only Retain information for future reference </td> <td style="text-align: center;"> <small>ADVERTENCIA: PELIGRO DE ASFIXIA</small> -Contiene piezas pequeñas Esto es un artículo de decoración navideña, NO ES UN JUGUETE Mantener fuera del alcance de los niños pequeños Sólo con fines decorativos Guardar esta información para futuras referencias </td> </tr> </table>	<small>WARNING:</small> CHOKING HAZARD - Small parts This is a Christmas decoration, NOT A TOY Keep out of reach of young children For decorative purpose only Retain information for future reference	<small>ADVERTENCIA: PELIGRO DE ASFIXIA</small> -Contiene piezas pequeñas Esto es un artículo de decoración navideña, NO ES UN JUGUETE Mantener fuera del alcance de los niños pequeños Sólo con fines decorativos Guardar esta información para futuras referencias
<small>WARNING:</small> CHOKING HAZARD - Small parts This is a Christmas decoration, NOT A TOY Keep out of reach of young children For decorative purpose only Retain information for future reference	<small>ADVERTENCIA: PELIGRO DE ASFIXIA</small> -Contiene piezas pequeñas Esto es un artículo de decoración navideña, NO ES UN JUGUETE Mantener fuera del alcance de los niños pequeños Sólo con fines decorativos Guardar esta información para futuras referencias					
	1474	2PK BEADED ROBIN	2PK BEADED ANIMAL HANGING DECORATION	<table border="1" data-bbox="922 1157 1384 1284"> <tr> <td style="text-align: center;"> <small>WARNING:</small> CHOKING HAZARD - Small parts This is a Christmas decoration, NOT A TOY Keep out of reach of young children For decorative purpose only Retain information for future reference </td> <td style="text-align: center;"> <small>ADVERTENCIA: PELIGRO DE ASFIXIA</small> -Contiene piezas pequeñas Esto es un artículo de decoración navideña, NO ES UN JUGUETE Mantener fuera del alcance de los niños pequeños Sólo con fines decorativos Guardar esta información para futuras referencias </td> </tr> </table>	<small>WARNING:</small> CHOKING HAZARD - Small parts This is a Christmas decoration, NOT A TOY Keep out of reach of young children For decorative purpose only Retain information for future reference	<small>ADVERTENCIA: PELIGRO DE ASFIXIA</small> -Contiene piezas pequeñas Esto es un artículo de decoración navideña, NO ES UN JUGUETE Mantener fuera del alcance de los niños pequeños Sólo con fines decorativos Guardar esta información para futuras referencias
<small>WARNING:</small> CHOKING HAZARD - Small parts This is a Christmas decoration, NOT A TOY Keep out of reach of young children For decorative purpose only Retain information for future reference	<small>ADVERTENCIA: PELIGRO DE ASFIXIA</small> -Contiene piezas pequeñas Esto es un artículo de decoración navideña, NO ES UN JUGUETE Mantener fuera del alcance de los niños pequeños Sólo con fines decorativos Guardar esta información para futuras referencias					

	<p>2PK BEADED HEART AND STAR HANGING DECORATION</p>	<p>2PK BEADED HEART AND STAR HANGING DECORATION</p>	<p>WARNING: CHOKING HAZARD - Small parts This is a Christmas decoration, NOT A TOY Keep out of reach of young children For decorative purpose only Retain information for future reference</p> <p>ADVERTENCIA: PELIGRO DE ASFIXIA -Contiene piezas pequeñas Esto es un artículo de decoración navideña, NO ES UN JUGUETE Mantener fuera del alcance de los niños pequeños Sólo con fines decorativos Guardar esta información para futuras referencias</p>
	<p>2PK BEADED ANGEL HANGING DECORATION</p>	<p>2PK BEADED ANGEL HANGING DECORATION</p>	<p>WARNING: CHOKING HAZARD - Small parts This is a Christmas decoration, NOT A TOY Keep out of reach of young children For decorative purpose only Retain information for future reference</p> <p>ADVERTENCIA: PELIGRO DE ASFIXIA -Contiene piezas pequeñas Esto es un artículo de decoración navideña, NO ES UN JUGUETE Mantener fuera del alcance de los niños pequeños Sólo con fines decorativos Guardar esta información para futuras referencias</p>
	<p>DECAL CANDLE</p>	<p>2 Wik Glass Jar Robin Decal candle</p>	 <p>WARNING LABEL - Insight holder Base Sticker</p> <p>5cm</p> <p>FRONT</p> <p>INSIDE OF STICKER</p>
	<p>SPICED QUINCE CANDLE</p>	<p>TUMBLER CANDLE MADE IN IRELAND IN SEASONAL SPICED QUINCE SCENT</p>	<p>PLEASE SEE WARNING ON CANDLE BOX AND JAR. NEVER LEAVE A CANDLE UNATTENDED</p>
	<p>FIR NOEL CANDLE</p>	<p>SCENTED CHRISTMAS CANDLE</p>	<p>WARNING - NEVER LEAVE A BURNING CANDLE UNATTENDED. REMOVE ALL PACKAGING BEFORE USE. BURN CANDLE OUT OF REACH OF CHILDREN AND PETS. BURN CANDLE ON FLAT HEAT RESISTANT SURFACE AND LEAVE 10CM BETWEEN BURNING CANDLES. DO NOT BURN CANDLES ON OR NEAR ANYTHING THAT CAN CATCH FIRE. DO NOT BURN CANDLES TO THE BASE. DISCONTINUE USE 15MM FROM THE BASE. ALWAYS EXTINGUISH CAREFULLY. DO NOT BURN CANDLES LONGER THAN 4 HOURS AT A TIME. TO AVOID THE CANDLE TUNNELING DOWN THE MIDDLE AND LEAVE LARGE RESIDUE OF WAX PLEASE ENSURE THAT CANDLE IS BURNT UNTIL THE WAX LIQUEFIES TO THE EDGE OF THE CONTAINER. DO NOT PLACE CANDLES IN A DRAUGHT IN DIRECT SUNLIGHT OR NEAR A SOURCE OF HEAT. TRIM WICK TO 1CM BEFORE LIGHTING. BURN IN AN UPRIGHT POSITION. IF FLAME GROWS TOO LARGE OR SMOKE EXTINGUISH CANDLE, ALLOW TO COOL, TRIM WICK, REMOVE ALL TRIMMINGS AND RELIGHT. KEEP THE WICK CENTERED. DO NOT ALLOW THE WICK TO TOUCH THE SIDE OF THE CONTAINER. KEEP THE WAX POOL CLEAR OF MATCHES AND DEBRIS TO AVOID FLARING. DO NOT MOVE A BURNING OR RECENTLY EXTINGUISHED CANDLE. DO NOT POUR HOT WAX. PROTECT SURFACES THAT MAY BE DAMAGED BY HEAT OR DRIPPING WAX. ALWAYS USE A CANDLE HOLDER TO CONTAIN SPILLAGES.</p>
	<p>CHRISTMAS SCENT</p>	<p>SCENTED CHRISTMAS CANDLE</p>	<p>WARNING - NEVER LEAVE A BURNING CANDLE UNATTENDED. REMOVE ALL PACKAGING BEFORE USE. BURN CANDLE OUT OF REACH OF CHILDREN AND PETS. BURN CANDLE ON FLAT HEAT RESISTANT SURFACE AND LEAVE 10CM BETWEEN BURNING CANDLES. DO NOT BURN CANDLES ON OR NEAR ANYTHING THAT CAN CATCH FIRE. DO NOT BURN CANDLES TO THE BASE. DISCONTINUE USE 15MM FROM THE BASE. ALWAYS EXTINGUISH CAREFULLY. DO NOT BURN CANDLES LONGER THAN 4 HOURS AT A TIME. TO AVOID THE CANDLE TUNNELING DOWN THE MIDDLE AND LEAVE LARGE RESIDUE OF WAX PLEASE ENSURE THAT CANDLE IS BURNT UNTIL THE WAX LIQUEFIES TO THE EDGE OF THE CONTAINER. DO NOT PLACE CANDLES IN A DRAUGHT IN DIRECT SUNLIGHT OR NEAR A SOURCE OF HEAT. TRIM WICK TO 1CM BEFORE LIGHTING. BURN IN AN UPRIGHT POSITION. IF FLAME GROWS TOO LARGE OR SMOKE EXTINGUISH CANDLE, ALLOW TO COOL, TRIM WICK, REMOVE ALL TRIMMINGS AND RELIGHT. KEEP THE WICK CENTERED. DO NOT ALLOW THE WICK TO TOUCH THE SIDE OF THE CONTAINER. KEEP THE WAX POOL CLEAR OF MATCHES AND DEBRIS TO AVOID FLARING. DO NOT MOVE A BURNING OR RECENTLY EXTINGUISHED CANDLE. DO NOT POUR HOT WAX. PROTECT SURFACES THAT MAY BE DAMAGED BY HEAT OR DRIPPING WAX. ALWAYS USE A CANDLE HOLDER TO CONTAIN SPILLAGES.</p>
	<p>ACCESSORY BOX</p>	<p>Leather accessory</p>	<p>Wipe clean with dry cloth</p>

	1488	JEWELLERY BOX	Leather jewerally box	Wipe clean with dry cloth
	1489	CHESS SET	Leather chess set in carry case.	Wipe clean with dry cloth
	1490	LEATHER NOTEBOOK	Leather notebook with linear paper	Wipe clean with dry cloth
	1491	LEATHER HIP FLAS	Leather Hip Flask	Wipe clean with dry cloth
	1492	BAR TOOLS SET	Bar tool sets including cork screw, hip flask and leather bar over in leather gift case	Wipe clean with dry cloth
	1493	SILK GIFT SET	Champagne silk eye mask and pillowcase	wash at 40 degrees
	1494	SILK GIFT SET	Ivory silk eye mask and pillowcase	wash at 40 degrees
	1495	CASHMERE GIFT SE	Cashmere eye mask and cashmere sock set	wash at 40 degrees
	1496	IVORY FUR THROW	Fur throw	Dry clean only
	1497	GREY FUR THROW	Fur throw	Dry clean only
	1499	IVORY FUR CUSHIO	Fur feather filled Cushion	Dry clean only
	1500	GREY FUR CUSHIO	Fur feather filled Cushion	Dry clean only
	1501	BROWN FUR CUSHIO	Fur feather filled Cushion	Dry clean only
	1502	DECADENCE CUSHION	Red decadence cushion	Dry clean only
	1503	RED VELOUR CUSHION	Red feather filled velour cushion	Dry clean only
	1504	TASSEL CUSHION	Cushion with gold trim and tassel	Dry clean only
	1505	COSTELLOE BEAR	Teddy bear in stripe jumper	spot clean only

	1506	PC TEDDY	Teddy bear with scarf	spot clean only
	1507	FUR TEDDY BEAR	Teddy Bear	spot clean only
	1508	GIANT BROWN BEAR	Large teddy bear with bow	spot clean only
	1509	GIANT POLAR BEAR	Large teddy bear with bow	spot clean only
	1510	CREST CANDLE	Candle with engraved PC lid	WARNING - NEVER LEAVE A BURNING CANDLE UNATTENDED. REMOVE ALL PACKAGING BEFORE USE. BURN CANDLE OUT OF REACH OF CHILDREN AND PETS. BURN CANDLE ON FLAT HEAT RESISTANT SURFACE AND LEAVE 10CM BETWEEN BURNING CANDLES. DO NOT BURN CANDLES ON OR NEAR ANYTHING THAT CAN CATCH FIRE. DO NOT BURN CANDLES TO THE BASE. DISCONTINUE USE 15MM FROM THE BASE. ALWAYS EXTINGUISH CAREFULLY. DO NOT BURN CANDLES LONGER THAN 4 HOURS AT A TIME. TO AVOID THE CANDLE TUNNELING DOWN THE MIDDLE AND LEAVE LARGE RESIDUE OF WAX PLEASE ENSURE THAT CANDLE IS BURNT UNTIL THE WAX LIQUEFIES TO THE EDGE OF THE CONTAINER. DO NOT PLACE CANDLES IN A DRAUGHT IN DIRECT SUNLIGHT OR NEAR A SOURCE OF HEAT. TRIM WICK TO 1CM BEFORE LIGHTING. BURN IN AN UPRIGHT POSITION. IF FLAME GROWS TOO LARGE OR SMOKES EXTINGUISE CANDLE, ALLOW TO COOL, TRIM WICK, REMOVE ALL TRIMMINGS AND RELIGHT. KEEP THE WICK CENTERED. DO NOT ALLOW THE WICK TO TOUCH THE SIDE OF THE CONTAINER. KEEP THE WAX POOL CLEAR OF MATCHES AND DEBRIS TO AVOID FLARING. DO NOT MOVE A BURNING OR RECENTLY EXTINGUISHED CANDLE. DO NOT POUR HOT WAX. PROTECT SURFACES THAT MAY BE DAMAGED BY HEAT OR DRIPPING WAX. ALWAYS USE A CANDLE HOLDER TO CONTAIN SPILLAGES.
	1511	CREST CANDLE	Candle with engraved PC lid	WARNING - NEVER LEAVE A BURNING CANDLE UNATTENDED. REMOVE ALL PACKAGING BEFORE USE. BURN CANDLE OUT OF REACH OF CHILDREN AND PETS. BURN CANDLE ON FLAT HEAT RESISTANT SURFACE AND LEAVE 10CM BETWEEN BURNING CANDLES. DO NOT BURN CANDLES ON OR NEAR ANYTHING THAT CAN CATCH FIRE. DO NOT BURN CANDLES TO THE BASE. DISCONTINUE USE 15MM FROM THE BASE. ALWAYS EXTINGUISH CAREFULLY. DO NOT BURN CANDLES LONGER THAN 4 HOURS AT A TIME. TO AVOID THE CANDLE TUNNELING DOWN THE MIDDLE AND LEAVE LARGE RESIDUE OF WAX PLEASE ENSURE THAT CANDLE IS BURNT UNTIL THE WAX LIQUEFIES TO THE EDGE OF THE CONTAINER. DO NOT PLACE CANDLES IN A DRAUGHT IN DIRECT SUNLIGHT OR NEAR A SOURCE OF HEAT. TRIM WICK TO 1CM BEFORE LIGHTING. BURN IN AN UPRIGHT POSITION. IF FLAME GROWS TOO LARGE OR SMOKES EXTINGUISE CANDLE, ALLOW TO COOL, TRIM WICK, REMOVE ALL TRIMMINGS AND RELIGHT. KEEP THE WICK CENTERED. DO NOT ALLOW THE WICK TO TOUCH THE SIDE OF THE CONTAINER. KEEP THE WAX POOL CLEAR OF MATCHES AND DEBRIS TO AVOID FLARING. DO NOT MOVE A BURNING OR RECENTLY EXTINGUISHED CANDLE. DO NOT POUR HOT WAX. PROTECT SURFACES THAT MAY BE DAMAGED BY HEAT OR DRIPPING WAX. ALWAYS USE A CANDLE HOLDER TO CONTAIN SPILLAGES.
	1512	PC BOW CANDLE	Candle in bow gift box	WARNING - NEVER LEAVE A BURNING CANDLE UNATTENDED. REMOVE ALL PACKAGING BEFORE USE. BURN CANDLE OUT OF REACH OF CHILDREN AND PETS. BURN CANDLE ON FLAT HEAT RESISTANT SURFACE AND LEAVE 10CM BETWEEN BURNING CANDLES. DO NOT BURN CANDLES ON OR NEAR ANYTHING THAT CAN CATCH FIRE. DO NOT BURN CANDLES TO THE BASE. DISCONTINUE USE 15MM FROM THE BASE. ALWAYS EXTINGUISH CAREFULLY. DO NOT BURN CANDLES LONGER THAN 4 HOURS AT A TIME. TO AVOID THE CANDLE TUNNELING DOWN THE MIDDLE AND LEAVE LARGE RESIDUE OF WAX PLEASE ENSURE THAT CANDLE IS BURNT UNTIL THE WAX LIQUEFIES TO THE EDGE OF THE CONTAINER. DO NOT PLACE CANDLES IN A DRAUGHT IN DIRECT SUNLIGHT OR NEAR A SOURCE OF HEAT. TRIM WICK TO 1CM BEFORE LIGHTING. BURN IN AN UPRIGHT POSITION. IF FLAME GROWS TOO LARGE OR SMOKES EXTINGUISE CANDLE, ALLOW TO COOL, TRIM WICK, REMOVE ALL TRIMMINGS AND RELIGHT. KEEP THE WICK CENTERED. DO NOT ALLOW THE WICK TO TOUCH THE SIDE OF THE CONTAINER. KEEP THE WAX POOL CLEAR OF MATCHES AND DEBRIS TO AVOID FLARING. DO NOT MOVE A BURNING OR RECENTLY EXTINGUISHED CANDLE. DO NOT POUR HOT WAX. PROTECT SURFACES THAT MAY BE DAMAGED BY HEAT OR DRIPPING WAX. ALWAYS USE A CANDLE HOLDER TO CONTAIN SPILLAGES.
	1513	LUXURY CRACKER	6 pack luxury cracker. Plastic free content, cracker and packaging recyclable.	Fireworks suitable for indoor use <ul style="list-style-type: none"> •Not for sale to persons under 12 years of age •Warning: Do not pull snap outside party cracker •Pull cracker away from face, food and drinks •Do not pull near eyes or ears •Pull both ends at arms length firmly and sharply •Do not remove snap •Adult supervision required •Not suitable for children under 3 years due to small parts which could represent a choking hazard and functional sharp points/edges which could cause an injury if misused •Please retain information for future reference •Please dispose of packaging safely

	1514	LUXURY CRACKER	6 pack luxury cracker. Plastic free content, cracker and packaging recyclable.	<p>Fireworks suitable for indoor use</p> <ul style="list-style-type: none"> •Not for sale to persons under 12 years of age •Warning: Do not pull snap outside party cracker •Pull cracker away from face, food and drinks •Do not pull near eyes or ears •Pull both ends at arms length firmly and sharply •Do not remove snap •Adult supervision required •Not suitable for children under 3 years due to small parts which could represent a choking hazard and functional sharp points/edges which could cause an injury if misused •Please retain information for future reference •Please dispose of packaging safely
	1515	LUXURY CRACKER	6 pack luxury cracker. Plastic free content, cracker and packaging recyclable.	<p>Fireworks suitable for indoor use</p> <ul style="list-style-type: none"> •Not for sale to persons under 12 years of age •Warning: Do not pull snap outside party cracker •Pull cracker away from face, food and drinks •Do not pull near eyes or ears •Pull both ends at arms length firmly and sharply •Do not remove snap •Adult supervision required •Not suitable for children under 3 years due to small parts which could represent a choking hazard and functional sharp points/edges which could cause an injury if misused •Please retain information for future reference •Please dispose of packaging safely
	1516	6PK CRACKER	6 pack family cracker with plastic free content, joke and a hat. Cracker barrell and packaging fully recyclable.	<p>Fireworks suitable for indoor use</p> <ul style="list-style-type: none"> •Not for sale to persons under 12 years of age •Warning: Do not pull snap outside party cracker •Pull cracker away from face, food and drinks •Do not pull near eyes or ears •Pull both ends at arms length firmly and sharply •Do not remove snap •Adult supervision required •Not suitable for children under 3 years due to small parts which could represent a choking hazard and functional sharp points/edges which could cause an injury if misused •Please retain information for future reference •Please dispose of packaging safely
	1517	6PK CRACKER	6 pack cracker with origami decoration, hat and a joke. Cracker barrell and packaging fully recyclable	<p>Fireworks suitable for indoor use</p> <ul style="list-style-type: none"> •Not for sale to persons under 12 years of age •Warning: Do not pull snap outside party cracker •Pull cracker away from face, food and drinks •Do not pull near eyes or ears •Pull both ends at arms length firmly and sharply •Do not remove snap •Adult supervision required •Not suitable for children under 3 years due to small parts which could represent a choking hazard and functional sharp points/edges which could cause an injury if misused •Please retain information for future reference •Please dispose of packaging safely



1518 6PK CRACKER

6 pack family crackers with kids game included, hat and a joke. Cracker barrel and packaging fully recyclable.

Fireworks suitable for indoor use

- Not for sale to persons under 12 years of age
- Warning: Do not pull snap outside party cracker
- Pull cracker away from face, food and drinks
- Do not pull near eyes or ears
- Pull both ends at arms length firmly and sharply
- Do not remove snap
- Adult supervision required
- Not suitable for children under 3 years due to small parts which could represent a choking hazard and functional sharp points/edges which could cause an injury if misused
- Please retain information for future reference
- Please dispose of packaging safely